



# Bello Stool - User Instructions


## 1. Functions



tilting




swiveling




up and down -- pull the strap

## 2. Fabric Recovery

After an extended period of time in the full height position, the fabric may loosen when moved to a lower position. The fabric will "recover" and appear without wrinkles after approximately 15 minutes.



Accidental depressions in the fabric will smoothen out when the stool is raised and lowered a few times.



Twist the plastic cover on the bottom of the Bello stool to "untwist" fabric as needed.